

HOW TO INSTALL A STANWOOD® RAIN CHAIN

Place attachment piece in gutter hole.

Remove old downspout.

Copper attachment piece (can be adjusted to fit the gutter)

Gutter hole

Hang the rain chain firmly onto the attachment piece.

Optional:

Reducer

Basin

ANY QUESTIONS PLEASE CONTACT US AT:
stanwoodimports@yahoo.com
sales@orientalhomegarden.com

Tel: (888) 670-5570

Copyright © Stanwood Imports / Oriental Touch LLC

