


# HOW TO USE YOUR AMISH STYLE YARN SWIFT



## STEP 1.

Make sure you have all the parts: two pieces of base, two yarn holding bars, 4 long pegs and 1 short peg.





## STEP 2.

Put two pieces of the base together and insert the short peg into the hole in the center of the base.

## STEP 3.

Put the two pieces of yarn holding bars together and slide it into the short peg on top of the base. Insert the long pegs into the holes of the yarn holding bars.



## STEP 4.

Untwist a skein of yarn so it becomes an open circle. Gently loop the yarn around the 4 pegs. Adjust the pegs so that the skein fits tightly around them.

## STEP 5.

Identify the end of the yarn that points to the outside of the skein. Pulling the outside end won't tangle the yarn. You may knit straight from the swift or wind the yarn into a center-pull ball using our ball winder (sold separately).

ANY QUESTIONS PLEASE CONTACT US AT:

[stanwoodimports@yahoo.com](mailto:stanwoodimports@yahoo.com)  
[sales@orientalhomegarden.com](mailto:sales@orientalhomegarden.com)

Tel: (888) 670-5570

Copyright © Stanwood Imports / Oriental Touch LLC

