

Instructions for Pole Anchoring




Parts for pole anchoring




1

Hammer the main pole into the ground using a **Rubber Mallet** until the black line touches the ground (about 1 ft deep).




2

Slide a support stake into the main pole and hammer it into the ground .



3

Slide a second support stake into the main pole. Position it 120 degrees away from the first stake and hammer it into the ground.



4

Slide a third support stake in to the main pole. Position it evenly away from earlier two stakes and hammer it into the ground.





5

Securely Installed Pole

Any questions or comments please contact us at stanwoodimports@yahoo.com Or sales@orientalhomegarden.com


Assembly Instructions For Copper Wind Sculptures

(For models CWS-01, -02 and -03)



Incorrect

Fix the pole firmly into the ground (See separate Instructions).






Mount spinner wheels onto the T-shaped shaft with **the exposed side of the bearings facing away from the T shaft.**

Correct

Connect two sections of the pole together.



Fix the wheels with provided mushroom ball screws to both ends of the T shaft. **Hand tighten as much as possible.**



Slide spinners into the pole.



Any questions or comments please contact us at stanwoodimports@yahoo.com
Copyright © 2003-2013, Stanwood Imports